

Selleys Super Glue Adjustable Gel

Description

Selleys Super Glue Adjustable Gel is ideal for everyday household repairs. It sets in 30 seconds, allowing time for users to adjust their fix to perfectly align their break. It's easy to use, requires no mixing and offers excellent adhesion to a variety of substrates.

Product Information

Packaging	Size
Tube	4x1g
Tube	3g

Uses

Great for repairs on surfaces such as ceramics, china, metal, wood & most plastics*

Features

- More time to adjust & reposition
- Works on ceramics, china, metal, wood & most plastics*.
- No mixing required.
- Gel consistency is ideal for vertical applications.

Technical Details

Property	Typical Result
Technology	Cyanoacrylate
Colour	Colourless to straw
Specific gravity	1.1
Set Time [^]	30 seconds
Cure Time	24 to 48 hours
Indicative data only, not intended for preparation of specifications	

Surface Preparation

Ensure surfaces to be bonded are clean, dry, free of dust, and close fitting.

Directions for Use

- Pierce seal at the end of the tube by attaching nozzle and cap; and turn clockwise.
- Remove cap and apply a small amount of glue to one surface; bring surfaces together and apply slight pressure.
- Allow 30 minutes for sufficient bond strength for practical use. Maximum bond strength reached after 24 hours.

Tips

- May cause leather to discolour or harden, if in doubt test on a small hidden area first.
- Wipe tip of tube after use and replace cap immediately.

Clean Up

- Uncured product may be removed with acetone.
- Cured product can be sanded and scraped.

Storage

Keep containers closed. Store in a cool, dry, well-ventilated place and out of direct sunlight.

Limitations

- *Will not bond Teflon, polyethylene, polypropylene.
- Not recommended for repairing handles of vessels that contain hot liquids.
- [^]Set time and cure rate depend on the type, condition and closeness of the surfaces; and atmospheric conditions.

Warnings, First Aid and Shipping Information

This information can be located on the product SDS found through our website – www.selleys.com